



# Welding Inspection

Welding Inspection Practical

Course Reference WIS 5

# Plate Inspection Practice

The purpose of this session is to practice the reporting format required by CSWIP in the practical plate examination part of the CSWIP 3.1 Welding Inspectors exam

Remember the responsibilities of a Welding Inspector are:

- **Observe**
- **Report**
- **Compare**

# Observe

---

To observe welding imperfections you are required to have good close vision acuity

A close vision acuity test will be given to you before your exam to establish if your vision meets the minimum standard required

**Its not just the project that must meet the standard!!**


You will also require a thorough knowledge of welding imperfections and their likely location, causes and implications

# Specialist Welding Gauges

A number of specialist welding gauges are available to measure the various elements that need to be measured in a welded fabrication including

- **TWI Multi-function weld gauge** for measuring many different weld measurements.
- **Fillet weld gauges** for measuring leg lengths and throat thickness.
- **Hi-Lo gauge** for measuring misalignment and root gaps
- **Angle gauges** for measuring weld preparation angles

# TWI Multi~purpose Welding Gauge




Angle of preparation

The scale reads from 0° to 60° in steps of 5°.

The angle is read against the chamfered edge of the segment


## Gauge



### Misalignment

The scale is used to measure misalignment of components by placing the edge of the gauge on the lower one and rotating the segment until the pointer contacts the higher piece


# TWI Multi~purpose Welding Gauge



## Undercut

The scale reads from 0 in the negative up to 5m. The segment is rotated until the pointer reaches the full depth of the undercut.

# TWI Multi~purpose Welding Gauge



Excess weld metal

The scale is used to read off these dimensions up to a maximum of 25mm and 1 inch




# TWI Multi~purpose Welding Gauge

---

---


WI 3.1



Fillet weld leg length

The scale is used to read off these dimensions up to a maximum of 25mm and 1 inch.


# TWI Multi~purpose Welding Gauge




## Fillet throat thickness

The sliding pointer reads up to 20mm and 3/4 inch. In measuring throat thickness it is assumed that the fillet weld has normal root penetration


# Fillet Weld Gauges



Leg Length Gauge





Throat Thickness Gauge



# HI~LO Welding Gauge

TECHNOLOGY



# Plate ~ Pipe Inspection

TECHNOLOGY



# Plate Inspection Practice

Remember in the CSWIP 3.1 Welding Inspectors examination you are required to conduct a practical examination of a plate test weld, complete a thumb print sketch and a final report on your findings

- Time allowed 1 hour and 15 minutes
- The code is provided



# Plate Inspection Points

- 1) Use a pencil for the arrow lines, but make all written comments and measurements in **ink only**
- 2) Report **everything** that you can observe
- 3) Do not forget to **compare and sentence** your report
- 4) Do not forget to **date & sign** your report
- 5) Make any observations, such as recommendations for further investigation for crack-like imperfections.

# Thumb Print Report Sketch

After you have observed an imperfection and determined its type, you must be able to take measurements and complete the thumb print report sketch

The first thumb print report sketch should be in the form of a repair map of the weld. (i.e. **All** observations are **Identified Sized and Located**)

The thumb print report sketch used in CSWIP exam will look like the following example.





# Plate Thumb Print Report

WI 3.1

## Example

Name (Block capitals) Joe BLOGGS

Signature Joe Bloggs

Test piece identification Example

Code used PH6/WI/00


Welding process MMA (SMAW)

Joint type Single V Butt

Welding position Flat 1G/PA

Length & thickness L=300mm D = 12.5mm

Date 16/07/02



# Final Report

After you have completed your thumb print report sketch of your test plate the next step is to complete your final report again the report must be **completed in ink (no pencil)**.

The report must be completed to your thumb print sketch, do not leave any boxes empty, **every box must be completed or dashed out**. You must also make any comments you feel are necessary regarding any defects observed.

The report form used in CSWIP will look like the following example.

# Plate Final Report Example

## EXTERNAL DEFECTS

Defect Type	Plate/Pipe Section	Defects Noted Accumulative Total	Code or Specification Reference		
			Maximum Allowable	Section No	Accept Reject
Reinforcement (Height)	<i>A - C</i>	<i>L = 300 H=2.5 max</i>	<i>2.0 mm</i>	<i>14</i>	<i>Reject</i>
Reinforcement (Appear)	<i>A - C</i>	<i>L=300 Not smooth</i>	<i>Smooth</i>	<i>14</i>	<i>Reject</i>
Incomplete filling	<i>A - B</i>	<i>L=24</i>	<i>None</i>	<i>13</i>	<i>Reject</i>
Inadequate weld width	<i>A - C</i>	<i>None</i>	—	—	<i>Accept</i>
Slag Inclusions	<i>A - C</i>	<i>None</i>	—	—	<i>Accept</i>
Undercut	<i>A - B</i>	<i>L=24 D=1.5 sharp</i>	<i>10% t</i>	<i>2</i>	<i>Reject</i>
Surface Porosity	<i>A - C</i>	<i>None</i>	—	—	<i>Accept</i>
Cracks/Cracklike Defect	<i>A - B</i>	<i>L=8mm</i>	<i>None</i>	<i>6</i>	<i>Reject</i>
Lack of fusion	<i>A - C</i>	<i>None</i>	—	—	<i>Accept</i>
Arc Strike	<i>A - B</i>	<i>2 Areas</i>	<i>None</i>	<i>4</i>	<i>Reject</i>
Mechanical Damage	<i>A - B</i>	<i>2 Areas smooth</i>	<i>Seek Advice</i>	<i>15</i>	<i>Refer</i>
Laminations	<i>A - C</i>	<i>None</i>	—	—	<i>Accept</i>
Misalignment	<i>A - C</i>	<i>None</i>	—	—	<i>Accept</i>
Longitudinal Seams	<i>A - C</i>	<i>None</i>	<i>Pipe only</i>	—	<i>Accept</i>



# Plate Final Report Example

TECHNOLOGY

## ROOT DEFECTS

Misalignment	<i>A - C</i>	<i>None</i>	—	—	<i>Accept</i>
Excessive Penetration	<i>B - C</i>	<i>L=24 D=2.5mm</i>	<i>2.0 mm</i>	<i>1</i>	<i>Reject</i>
Lack of Penetration	<i>B - C</i>	<i>L=10</i>	<i>25 mm</i>	<i>11</i>	<i>Accept</i>
Lack of Root Fusion	<i>A - C</i>	<i>None</i>	—	—	<i>Accept</i>
Root Concavity	<i>A - C</i>	<i>None</i>	—	—	<i>Accept</i>
Root Undercut	<i>A - B</i>	<i>L= 27 D=0.5 sharp</i>	<i>10% t</i>	<i>2</i>	<i>Accept</i>
Crack/Cracklike Defect	<i>A - C</i>	<i>None</i>	—	—	<i>Accept</i>
Slag Inclusions	<i>A - C</i>	<i>None</i>	—	—	<i>Accept</i>
Porosity	<i>A - C</i>	<i>None</i>	—	—	<i>Accept</i>

This **Pipe/plate** has been examined to the requirements of [code/specification] .....*BW/VI/00*.....

And is **accepted/rejected** accordingly.

Signature .....**MSRogers**..... Date .....**14/9/02**.....

**Use the other side for comments**

# Pipe Inspection Practice

Remember in the CSWIP 3.1 Welding Inspectors examination you are required to conduct a practical examination of a pipe test weld, complete a thumb print sketch and a final report on your findings

- Time allowed 1 hour and 45 minutes
- The code is nominated e.g API 1104





# Pipe Thumb Print Report

WI 3.1

## Example

TECHNOLOGY

Page 1 of 3

### VISUAL INSPECTION PIPE REPORT

Name [Block capitals]\_\_\_\_\_ Signature\_\_\_\_\_ Pipe Ident#\_\_\_\_\_

Code/Specification used\_\_\_\_\_ Welding Process\_\_\_\_\_ Joint type\_\_\_\_\_

Welding position\_\_\_\_\_ Outside Ø & Thickness\_\_\_\_\_ Date \_\_\_\_\_

A	B	C
-----		
C	D	A
-----		

**Complete as per plate report form**

# Pipe Code: API 11~4

Reinforcement Height:	7.8.2	page 20	Misalignment:	Not referenced
Reinforcement Appear:	7.8.2	page 20	Longitudinal seams:	Not referenced
Incomplete groove:	7.8.2	page 20	Excess penetration:	Not referenced
Inadequate weld width:	7.8.2	page 20	Lack of penetration:	9.3.1/9.3.2 page 21
Slag inclusions:	9.3.8	page 22	Lack of root fusion:	9.3.5 page 21
Undercut:	9.3.11	page 22	Concave root:	9.3.6 page 22
Porosity:	9.3.9	page 24	Burn through:	9.3.7 page 22
Cracks:	9.3.10	page 24		
Lack of fusion:	9.3.4	page 22		
Arc strikes/arc burns:	A.5.3	page 55		
Mechanical damage:	Not referenced			
Lamination:	Not referenced			

# Macro Inspection





# Macro Inspection Practice

Remember in the CSWIP 3.1 Welding Inspectors examination you are required to conduct a visual examination of two macro samples

- Time allowed 45 minutes
- Code ISO 5817 Level stringent B



## Instructions

### PLEASE READ CAREFULLY

You have been provided with one or two macro samples and the report sheets you are required to complete the following

1. Ensure that you record your name and the date on the report sheet
2. Ensure that you sign the report sheet
3. Visually inspect the specimens and report:  
The defects type  
The defects size, length, depth and height if applicable
4. Comment on each defect e.g accept, reject or refer in accordance with ISO 5817 stringent B

ALL LINE DRAWING & WRITING MUST BE COMPLETED IN INK

ALL MEASUREMENT IN MM / PHOTOGRAPH AT 10X MAGNIFICATION.

DIVIDE ALL MEASUREMENTS BY 10 AND RECORD ON REPORT PROVIDED

NO LIQUID PAPER OR CORRECTION FLUID PERMITTED. CORRECTIONS MUST BE CROSSED OUT AND THE CORRECTION MADE

TIME ALLOWED FOR TWO MARCS 45 MINUTES

### 3.2 Weld thickness

**3.2.1 fillet weld thickness,  $a$ ; nominal throat thickness:** Height of the largest isosceles triangle that can be inscribed in the weld section (see ISO 2553).

NOTE 1 In countries in which the leg length,  $z$ , is used as the dimension of a fillet weld, the limits for imperfections may be reformulated so that they refer to the leg length.

**3.2.2 butt weld thickness,  $s$ :** Minimum distance from the surface of the part to the bottom of the penetration, which cannot be greater than the thickness of the thinner of the parts (see ISO 2553).

**3.3 short imperfections:** One or more imperfections of total length not greater than 25 mm in any 100 mm length of the weld or a maximum of 25 % of the weld length for a weld shorter than 100 mm.

**3.4 long imperfection:** One or more imperfections of total length greater than 25 mm in any 100 mm length of the weld or a minimum of 25 % of the weld length for a weld shorter than 100 mm.

**3.5 projected area:** Area given by length of weld examined multiplied by the maximum width of weld.

**3.6 surface crack area:** Area to be considered after fracture.

## 4 Symbols

The following symbols are used in table 1.

- $a$  nominal fillet weld throat thickness (fillet thickness)
- $b$  width of weld reinforcement
- $d$  diameter of pore
- $h$  size (height or width) of imperfection
- $l$  length of imperfection
- $s$  nominal butt weld thickness or, in the case of partial penetration, the prescribed depth of penetration
- $t$  wall or plate thickness
- $z$  leg length of fillet welds (in case of isosceles right angle triangular section  $z = a\sqrt{2}$ )

## 5 Evaluation of welds

Limits for imperfections are given in table 1.

A welded joint should normally be evaluated separately for each individual type of imperfection (Nos. 1 to 25).

Different types of imperfection occurring at any cross-section of the joint may need special consideration (see No. 26).

Maximum pore diameter 3mm or pore diameter shall be less than or equal to 0.3 X plate thickness

Table 1 – Limits for imperfections

No.	Imperfection designation	ISO 8520 reference	Remarks	Limits for imperfections for quality levels		
				Moderate D	Intermediate C	Stringent B
1	Cracks	100	All types of cracks except micro cracks (20 μm), crater cracks, sea	Not permitted		
2	Crater crack	104		Permitted	Not permitted	
3	Porosity and gas pores	2011 2012 2014 2017	The following conditions and limits for imperfections shall be fulfilled:  a) Maximum dimension of the summation of the projected or surface crack area of the imperfection  b) Maximum dimension of a single pore for — butt welds — fillet welds  c) Maximum dimension for a single pore		2 %	1 %
				$d \leq 0,5 s$ 0,5 a 5 mm	$d \leq 0,4 s$ 0,4 a 4 mm	$d \leq 0,3 s$ 0,3 a 3 mm
4	Localized (clustered) porosity	2013	The total pore area within the cluster should be summed and calculated as a percentage of the greater of the two areas: an envelope surrounding all the pores or a circle with a diameter corresponding to the weld width.  The permitted porous area should be local. The possibility of masking other imperfections should be taken into consideration.  The following conditions and limits for imperfections shall be fulfilled:  a) Maximum dimension of the summation of the projected or surface crack area of the imperfection  b) Maximum dimension of a single pore for — butt welds — fillet welds  c) Maximum dimension for localized clustered porosity			
				16 %  $d \leq 0,5 s$ 0,5 a 4 mm	8 %  $d \leq 0,4 s$ 0,4 a 3 mm	4 %  $d \leq 0,3 s$ 0,3 a 2 mm

Acceptance levels B,C,D  
For the CSWIP 3.1 exam  
stringent B

# ISO 5817 Exercise

- Using **ISO 5817** determine the acceptability of the defects listed. Under the column headed specimen thickness, insert A,R and X
- Use the acceptance category **stringent B** when making your assessment assume specimens to be plate butt welds

**A = Accept**


**R = Reject**

**X = Refer**

		Specimen Thickness(mm)			
Defect	Dimensions	8	15	30	60
Overlap	H = 1.5	R	R	R	R
Incomplete penetration	L = 2.0	R	R	R	R
Lack of sidewall fusion	L = 2.0	R	R	R	R
Gas pore	D = 2.5	R	A	A	A
Slag inclusion	1.0 x 2.0	A	A	A	A
Elongated cavity	0.5 x 1.5	A	A	A	A
Linear misalignment	H = 1.8	R	R	A	A
Cap undercut	D = 0.4	A	A	A	A
Crack	L = 1.5	R	R	R	R
Spatter	D = 1.8	X	X	X	X

# Marco Report Example

CHECK PHOTOGRAPH IDENT MATCHES FORM SUPPLIED. **ALL LINE DRAWING & WRITING MUST BE IN INK.** ALL MEASUREMENTS IN MM / PHOTOGRAPH AT X10 MAGNIFICATION



RECORD DEFECTS AS YOU SEE THEM  
THESE MACROS HAVE BEEN MASTERED FROM  
THE PHOTOGRAPHS  
 INTERPRETATION DIFFICULTIES HAVE BEEN  
 RECORDED.

**COMMENT ONLY IF A DEFINITE UNCERTAINTY  
 EXISTS: i.e SLAG/GAS IN SOME CASES**

	DEFECT	SIZE	ACCEPT/REJECT
1	Lack of sidewall fusion + Slag	3 x 4 mm	Reject
2	Lack of sidewall fusion	3 mm	Reject
3	Slag inclusion	1.5 mm	Accept
4	Cap undercut	0.5 mm	Accept
5	Plate lamination	5.2 mm	Refer*
6			
7			
8			
10			
11	<b>Excess weld metal</b>	4 mm	Reject
12	<b>Excess root penetration</b>	None	Accept

**COMMENTS:** \*Materials defect acceptance dependent on application. Seek advice.

**Name:** Mark Rogers

**Signature:** M S Rogers

**Date:** 20/03/03



# Any Questions

TECHNOLOGY

